



Step 6:
Folding the fabric inwards, insert and adjust the universal remote to ensure proper fit and alignment.



Step 7:
The plastic access panel is too thin to adequately secure the locking tabs on the unit. The areas underneath the locking tabs will need to be built up. Close-up of JB Weld mounts used to allow for complete locking in of the universal remote into the access panel.

