

## Step 8:

Due to the complete lack of space in the sunroof motor area, I found it absolutely necessary to remove down the top plastic of the unit by carefully grinding it down along the sides. Carefully remove and retain the adhesive foam pad. Note: If this step is omitted, the transmitter will bulge the access panel severely, result in broken clips and look unsightly.



## Step 9:

Replace the foam pad in its original location.



**Step 10:**  
Make the connections to the sunroof switch and universal remote. Note: This illustration is prior to removal of top plastic of the transmitter (step 9).



**Step 11:**  
Carefully snap the panel back in as well as the cabin light and check operation off all the switches and program the universal remote. Directions are included with the unit.

